



7 Open the “Settings” page. (“Ayarlar” sayfasını açın.)

#### Device Port

COM6 wch.cn

Refresh Ports List

If there is no port named "wch.cn" in the list, download and install the driver CH340x from [Downloads](#) page and restart app.

SAVE

Select the port containing “wch.cn”. (“wch.cn” ifadesini içeren portu seçin.)

If there is no port named "wch.cn" in the list, download and install the driver CH340x from [geexlight.com/downloads](http://geexlight.com/downloads) page and restart app.

Eğer port listesinde “wch.cn” içeren port göremiyorsanız, [geexlight.com/downloads](http://geexlight.com/downloads) adresinden CH340x Sürücülerini indirin ve yükleyin. Sonrasında uygulamayı yeniden başlatın.